

Manual

A Velvet-series



Introduction

We thank you for your purchase of our Beamax A-Velvet series. Just like yourselves we have high demands regarding our products.

We therefore hope that you will be enjoying your screen for years to come.

To make sure you will have the maximum of pleasure with your screen it is important to read this manual before assembling your screen.

We wish you a lot of viewing pleasure!

Disclaimer

The guarantee on the A-velvet is 2 years. The guarantee ceases to apply if the screen is not installed correctly or used for any other purpose other than for which it has been designed.

Projection

Projection quality depends on many factors and will vary in different surroundings. Beamax can not offer any guarantee regarding perceived projection quality.

Changes may be made without prior notice.

Required materials and tools

Tools:

- Screwdriver
- Drillmachine

Material:

- Hanging hooks, screws and plugs (not included) for wall mounting purposes

Setting up the screen

General tips for setting up the screen:

Check that the product is delivered complete and in undamaged condition before attempting to install the product.

- See whether it is physically possible to mount the screen in the intended place. Make allowance for the load-bearing capacity of the wall and the securing points.
- Make certain that the bottom of the screen hangs sufficiently high (between 70 cm and 125 cm clear of the floor). This will provide optimum viewing comfort.
- Assembly is generally easier with 2 pair of hands.
- Make sure the room is dust free before you assemble the frame screen.

Note: In the production of this screen chemicals are used to make the screen more flexible. After the installation you will probably notice a smell that will decrease from day to day. There is no danger for your health. We recommend that you air out the room properly after you installed the screen.

Installation

1. Lay down the frame parts with the back side up.
2. Place the pins in the rail.
3. Slide the frame parts together by using the corner brackets.
4. Screw these plates onto the frame.
5. Pull the iron rods through the fabric on each side (4).
6. Put the fabric with the black side up and fix the fabric by pushing the pins through the openings in the fabric.
7. Turn the screen around and hang it on the wall.

Maintenance

A screen has a long service life provided it is used correctly. The following tips will help you to get the most out of your screen.

1. Protect the projection fabric from dust and smoke. Roll up when not in use.
2. Ensure when rolling up that the fabric is completely free of dust or other impurities.
3. Do not write on the fabric. It can be cleaned only to a limited extent, using a mild soap solution.
4. Do not leave the fabric exposed to direct sunlight for long periods. Direct sunlight may cause a yellow discoloration.

See www.beamax.com for the latest developments regarding Beamax projection screens.